




INSTALLATION INSTRUCTIONS

V-BRAKE THREADED

- Eagle 2™
- Vans®
- Continental



- Clean rim surface before installing new pads(
- Place new pads and finger tighten nuts(
- Align the pads correctly without touching the tire(
- Now tighten the nut with a force of 6-8 Nm.
- Check pad and rim alignment after the pads are broken in and after every ride.

IMPORTANT: Designed for bicycle use only. Do not ride bike until brakes are checked and functioning properly. All Kool-Stop Pads meet or exceed C.P.S.C. and D.I.N bicycle standards(